

INSTALLATION GUIDE OF STEP LIGHT-RECESSED





CAUTION:

Use a qualified electrician for installation of this lighting fixture.

Before installing fixture disconnect power by shutting off the circuit breaker or by removing the fuse at the fuse box.

All electrical connections must be in accordance with local and National Electrical Code or Canadian Electrical Code standards.

لـ	Horizontal Installation	*
1		For outdoor installation, use included gasket. Indoor applications, gasket is not required. Make wire connection inside of electrical box. Attach LED light engine to standard single gang electrical box using screws provided.
2		Place preferred trim style and finish over top of light engine. With included allen key, attach the trim to the light engine.
3		Turn back on electrical power. Turn light on from switch.

^{*} For 12V AC/DC, please follow standard low voltage wiring.



	Vertical Installation	
1		For outdoor installation, use included gasket. Indoor applications, gasket is not required. Make wire connection inside of electrical box. Attach LED light engine to standard single gang electrical box using screws provided.
2		Place preferred trim style and finish over top of light engine. With included allen key, attach the trim to the light engine.
3		Turn back on electrical power. Turn light on from switch.